



3,0 GSL MPI-ECU, UL, NACIONAL, EXPORTACION, GENERAL



3,0 GSL MPI - ECU (UL, EUROPE)




C 1	C 13	C 25
C 2	C 14	C 26
C 3	C 15	C 27
C 4	C 16	C 28
C 5	C 17	C 29
C 6	C 18	C 30
C 7	C 19	C 31
C 8	C 20	C 32
C 9	C 21	C 33
C 10	C 22	C 34
C 11	C 23	C 35
C 12	C 24	C 36
C 13	C 25	C 37


ECU DE MOTOR

TE LMR	HR 807030
YQ	INYE CIL 1
YL	INYE CIL 3
YB	INYE CIL 5
YR	MTR PASO A PASO (A)
YV	MTR PASO A PASO (B)
YW	NO UTIL
YX	NO UTIL
Y1	NO UTIL
Y2	NO UTIL
Y3	NO UTIL
Y4	NO UTIL
Y5	NO UTIL
Y6	NO UTIL
Y7	NO UTIL
Y8	NO UTIL
Y9	NO UTIL
Y10	NO UTIL
Y11	NO UTIL
Y12	NO UTIL
Y13	NO UTIL
Y14	NO UTIL
Y15	NO UTIL
Y16	NO UTIL
Y17	NO UTIL
Y18	NO UTIL
Y19	NO UTIL
Y20	NO UTIL
Y21	NO UTIL
Y22	NO UTIL
Y23	NO UTIL
Y24	NO UTIL
Y25	NO UTIL
Y26	NO UTIL
Y27	NO UTIL
Y28	NO UTIL
Y29	NO UTIL
Y30	NO UTIL
Y31	NO UTIL
Y32	NO UTIL
Y33	NO UTIL
Y34	NO UTIL
Y35	NO UTIL
Y36	NO UTIL
Y37	NO UTIL
Y38	NO UTIL
Y39	NO UTIL
Y40	NO UTIL
Y41	NO UTIL
Y42	NO UTIL
Y43	NO UTIL
Y44	NO UTIL
Y45	NO UTIL
Y46	NO UTIL
Y47	NO UTIL
Y48	NO UTIL
Y49	NO UTIL
Y50	NO UTIL
Y51	NO UTIL
Y52	NO UTIL
Y53	NO UTIL
Y54	NO UTIL
Y55	NO UTIL
Y56	NO UTIL
Y57	NO UTIL
Y58	NO UTIL
Y59	NO UTIL
Y60	NO UTIL
Y61	NO UTIL
Y62	NO UTIL
Y63	NO UTIL
Y64	NO UTIL
Y65	NO UTIL
Y66	NO UTIL
Y67	NO UTIL
Y68	NO UTIL
Y69	NO UTIL
Y70	NO UTIL
Y71	NO UTIL
Y72	NO UTIL
Y73	NO UTIL
Y74	NO UTIL
Y75	NO UTIL
Y76	NO UTIL
Y77	NO UTIL
Y78	NO UTIL
Y79	NO UTIL
Y80	NO UTIL
Y81	NO UTIL
Y82	NO UTIL
Y83	NO UTIL
Y84	NO UTIL
Y85	NO UTIL
Y86	NO UTIL
Y87	NO UTIL
Y88	NO UTIL
Y89	NO UTIL
Y90	NO UTIL
Y91	NO UTIL
Y92	NO UTIL
Y93	NO UTIL
Y94	NO UTIL
Y95	NO UTIL
Y96	NO UTIL
Y97	NO UTIL
Y98	NO UTIL
Y99	NO UTIL
Y100	NO UTIL

3 0 GSL SOHC SIN
PLOMO CON INMOVILIZADOR
T.M.L. CHAPA ORO

2,5 DIESEL CIRCUITO ELECTRICO





3,0 GASOLINA CIRCUITO ELECTRICO

